1. Download & install HYCO's upgrade App via the link below on your Android device:

http://hycosoft.com/ring_upgrade.apk

2. Open the App, the interface should look like pic 1;

3. Choose the name by the Ring Scanner's S/N, which is located on the bottom of the ring (as shown in the pic 2);

4. Choose "Ring Upgrade" and then click on "confirm" (pic 3);

5. Choose "Upgrade" (pic 4) and don't forget to pay attention to "Tips" section.